



**Floor Model
Extension Kit
Doubles The Size Of The
Q-Snap Floor Model**

Item 7792

Parts Included:

2	0811	23 7/8" tubes
2	0810	27 1/2" tubes
2	0809	34 1/4" tubes
2	0802	29 3/4" Q-Snap clamps
2	0823	T fitting **
2	0822	T slip fitting **
2	0821	Elbows
1	0844	box handle
		assembly instruction sheet

** notice the difference between the two T fittings. The slip fitting does not have a 'stop' and will slide on the tube.

Call 800-247-3952 if any parts are missing or damaged

**Call 800-247-3952
or email info@yarntree.com
if any parts are missing or damaged**

This frame is designed for use with regular batting. "Fat Batts" are too thick for the clamps. Any trapunto work should be done after quilting. The clamps fit snugly and are not designed to fit over stuffed work.

To protect your fabric and stitching, you may wish to place a piece of light weight fabric between your quilt and the clamps. Let your quilt breathe. Remove the clamps when not stitching.

Your Q-Snap Floor Frame is warranted for two years (please keep your purchase receipt). We will replace any defective parts during the warranty period for no charge. Replacement clamps may be available at your local retail store. All other replacement parts are available from the manufacturer. Call 800-247-3952 (515-232-3121 outside the USA). More information can be found at QSnap.com.

Yarn Tree



117 Alexander Avenue, Ames, IA 50010
yarntree.com info@yarntree.com
515-232-3121 800-247-3952

**The original tube and clamp frame.
Ask for it by name**



Made In the USA

Assembly Instructions - It's Easy! No Tools Needed!

Before you begin... Wash your frame before you put a quilt into it. Handling, shipping, and static can make it a bit dusty. A light once-over with a damp cloth and you are ready to quilt. Use only mild dish or hand soap to clean the frame and clamps. NEVER use petroleum based cleaners, solvents, or polish as these can damage the plastic. Extended exposure to direct sunlight will weaken all plastics and cause chalking and premature failure of the clamps.

Assemble your Q-Snap Floor Model as usual.

- 1 Separate one end of the Floor Model assembly as shown in the left and right hand dimmed out illustration.
- 2 Attach the two elbow fittings onto one of the 23 7/8" tubes.
- 3 Attach the two 27 1/2" tubes to the elbows. This creates the legs for the extension.
- 4 Attach the two T slip fittings onto the second 23 7/8" tube. (Notice the difference between the two T fittings. The slip fitting does not have a 'stop' and will allow a tube to slide through the fitting.)
- 5 Slide the two T slip fittings onto the 27 1/2" legs. If the tubes will not slide through the slip elbows, change the elbows.
- 6 Attach the two T fittings to the top of the 27 1/2" legs.
- 7 Attach the Extension legs to the two tubes of the Floor Model Frame.
- 8 Insert the two 34 1/4" extension tubes (parts e) as shown.
- 9 Attach the end of the Floor Model Frame to the extension tubes.

